DOTT-CC Compact Hand Pedaled Trike Kit

40 tooth chain wald 540 spiral pattern J & B #22168

28 tooth J & B #22889 crank set bearings for 1 piece crank J & B #22240

SHEET METAL PARTS (Not incl. Brake parts)

#1	HWI-DOTTU-T-001	Seat Back Mounting Plate	Odin Industries	Qty. 2	\$ <u></u> ea.
#2	HWI-DOTT-T-002	Universal Mounting Rail	Odin Industries	Qty. 3	\$ <u></u> ea.
#3	HWI-DOTTU-T-003	Steering Hinge Plate	Odin Industries	Qty. 1	\$ <u></u> ea.
#4	HWI-DOTTU-T-004	Steering Hinge Bracket	Odin Industries	Qty. 1	\$ <u></u> ea.
#5	HWI-DOTTU-T-005	Leg Support Mounting Plate	Odin Industries	Qty. 1	\$ <u></u> ea.
#6	HWI-DOTTU-T-006	Chain Wheel Cover	Odin Industries	Qty. 2	\$ <u></u> ea.
#7	<u>Number Not Used</u>				
#8	HWI-DOTTCC-T-008	Seat Support Strap	Odin Industries	Qty. 4	\$ <u></u> ea.
#9	HWI-DOTT-T-009	Foot Rest Support Plate	Odin Industries	Qty. 2	\$ ea.
		FINISHED TUBES			
#10	HWI-DOTTCC-T-010	Leg Rest Ankle Support Tube	Cain Tube. Prod.	Qty. 1	\$ ea.
#11	HWI-DOTTCC-T-011	Leg Rest Tube	Cain Tube. Prod.	Qty. 1	\$ ea.
#12	HWI-DOTTCC-T-012	Crank Assembly Tube	Cain Tube. Prod.	Qty. 1	\$ ea.
#13	HWI-DOTTCC-T-013	Chassis Seat Tube	Cain Tube. Prod.	Qty. 1	\$ ea.
#14	HWI-DOTTCC-T-014	Chassis Cross Tube	Cain Tube. Prod.	Qty. 1	\$ ea.
#15	HWI-DOTTCC-T-015	Chassis Left Side Top Tube	Cain Tube. Prod.	Qty. 1	\$ ea.
#16	HWI-DOTTCC-T-016	Chassis Left Side Bottom Tube	Cain Tube. Prod.	Qty. 1	\$ ea.
#17	HWI-DOTTCC-T-017	Fork Arm Tube	Cain Tube. Prod.	Qty. 2	\$ ea.
#18	HWI-DOTTCC-T-018	Steering Tube	Cain Tube. Prod.	Qty. 1	\$ ea.
#19	HWI-DOTTCC-T-019	Seat Back Tube	Cain Tube. Prod.	Qty. 1	\$ ea.
#20	HWI-DOTTCC-T-020	Haiti Brace	Cain Tube. Prod.	Qty. 1	\$ ea.

MISCELLANEOUS TUBE & ROD PIECES REQUIRED FOR FRAME

#21	N/A	Mild Steel Tube, ½" Dia. By .065" wall, 1.5" long (To Make Steering Tube Clamp)	via Odin Ind.	Qty. 1	\$ <u></u> ea.
#22	N/A	Mild Steel Tube,7/8" Dia. By .120" wall, 8.25" long (To Make Steering Hinge Tube)	via Odin Ind.	Qty. 1	\$ <u></u> ea.
#23	N/A	Mild Steel Tube,7/8" Dia. By .120" wall, 3.0" long (To Make Rear Axle Tubes)	via Odin Ind.	Qty. 2	\$ <u></u> ea.
#24	N/A	Mild Steel Tube,7/8" Dia. By .120" wall, 1.5" long (To Make Front Fork Axle Tubes)	via Odin Ind.	Qty. 2	\$ <u></u> ea.
#25	N/A	Mild Steel Tube,2-1/4" Dia. By .10" wall, 2.6" long (To Make Pedal Crank Shell)	via Odin Ind.	Qty. 1	\$ <u></u> ea.
#26	N/A	Mild Steel Rod, 5/8" Dia., 10.0" long (To Make Front & Rear Axles, Cross Drilled At One End For Cotter Pin, Flat Washer Welded To Other End To Retain Wheel, See Drawings)	via Odin Ind.	Qty. 3	\$ea.
#27	N/A	Mild Steel Rod, 5/8″ Dia., 10.0″ long (To Make Steering Hinge Shaft, Piece Of ¼″ Rod Welded To One End, See Drawings)	via Odin Ind.	Qty. 1	\$ea.

WHEELS

□ #28	N/A	Wheelbarrow Wheel, Sealed Ball Bearings .625" axle, 6" wide hub, 4.80/4.00-8" tire, diamond tread (Used for front wheel, must have gear added)	Marathon Industries	Qty. 1	\$ea.
□ #29	N/A	Wheelbarrow Wheel, Sealed Ball Bearings .625" axle, 3" wide hub, 4.80/4.00-8" tire, diamond tread (Used for rear wheels)	Marathon Industries	Qty. 2	\$ea.

- □ #31 <u>Number Not Used</u>
- #32 <u>Number Not Used</u>
- □ #33 <u>Number Not Used</u>

WOOD SEAT SURFACES

#37	Number Not Used				
 #36	HWI-DOTTCC-T-036	Seat Bottom Plywood Surface, ¼" Plywood	TBD	Qty. 1	\$ ea.
#35	HWI-DOTTCC-T-035	Foot Rest Plywood Surface, 3/8" Plywood	TBD	Qty. 1	\$ <u></u> ea.
#34	HWI-DOTTCC-T-034	Seat Back Plywood Surface, ¼" Plywood	TBD	Qty. 1	\$ ea.

- #38 <u>Number Not Used</u>
- □ #39 Number Not Used

SHEET METAL PARTS FOR DOWN HILL BRAKE

□ #40	HWI-DOTTU-T-040	Brake Lever & Steering Tiller Base	Odin Industries	Qty. 1	\$ ea.
□ #41	HWI-DOTTU-T-041	Brake Shoe	Odin Industries	Qty. 1	\$ ea.
□ #42	HWI-DOTTU-T-042	Brake Lock	Odin Industries	Qty. 1	\$ ea.
□ #43	HWI-DOTTU-T-043	Brake & Steering Tiller Mount	Odin Industries	Qty. 1	\$ ea.
□ #44	HWI-DOTTU-T-044	Brake Rod Upper Mounting Flange	Odin Industries	Qty. 1	\$ ea.
□ #45	HWI-DOTTU-T-045	Brake Rod Lower Mounting Flange	Odin Industries	Qty. 1	\$ <u></u> ea.

BOLTS, TUBE & HARDWARE FOR DOWN HILL BRAKE

□ #46	97045K54	Hand Grip, Vinyl, Black, 7/8"	McMaster-Carr	Qty. 1	\$8.00/6 approx.		
		(Used For Tiller Handle, Same As Part Used For Pedals)					
□ #47	AN4-6A	AN4 Series Bolt, Un-drilled, 5/16" Grip Length,	Aircraft Spruce	Qty. 1	\$.14 ea.		
		25/32" Nominal Length (Used For Lower Rod Attachment)					

#48	AN4-24A	AN4 Series Bolt, Un-drilled, 2-1/16" Grip Length, 2-17/32" Nominal Length (<i>Used For Tiller Attachment</i>)	Aircraft Spruce	Qty. 1	\$.47 ea.
#49	AN4-25A	AN4 Series Bolt, Un-drilled, 2-3/16" Grip Length, 2-21/32" Nominal Length (Used For Brake Shoe Attachn	Aircraft Spruce nent)	Qty. 1	\$.44 ea.
#50	AN4-26A	AN4 Series Bolt, Un-drilled, 2-5/16" Grip Length, 2-25/32" Nominal Length (Used For Upper Rod Attachm	Aircraft Spruce nent)	Qty. 1	\$.58 ea.
#51	xxxxxxxx	¼" Flat Washers	McMaster-Carr	Qty. 10	\$ ea.
#52	XXXXXXXXX	%-28 Plastic Insert Lock Nuts	McMaster-Carr	Qty. 4	\$ ea.
#53	9432K64	Spring, 3/8" Dia.,.055" Wire, 4.5" Long (Used For Brake Shoe Return Spring)	McMaster-Carr	Qty. 1	\$12.00/5
#54	N/A	Mild Steel Tube, ½" Dia. By .065" wall, <mark>" long</mark> (To Make Brake Rod)	via Odin Ind.	Qty. 1	\$ <u></u> ea.

BIKE PARTS FOR DRIVETRAIN

#55 #56	Standard bicycle chain, Standard 1/8" type "One piece" style bottom bracket bearing and cup set Pyramid P/N 22240 (Via J & B Distributors)	J&B J&B	Qty. 2 Qty. 1	\$ 4.00 ea. \$4.19 ea.
#57	"One piece" style crank arm set 24 TPI, 5.5" arm length Pyramid P/N 2232 (Via J & B Distributors)	J&B	Qty. 1	\$ 6.00.
#58	Chainring, 28 tooth (For Crank, Optional For Wheel) J & B P/N 22889	J&B	Qty. 2	\$ 5.00.

#59		Chainring, 40 tooth (Optional For Wheel) Wald 540 spiral pattern, J & B #22168	J&B	Qty. 1	\$
		HAND PEDAL ASSEMBLIES			
#60		Standard bicycle ½" steel pedal set (Modified by removing "rat trap")	J&B	Qty. 1	\$ ea.
#61		5/8" I.D. x 7/8" O.D. PVC Tubing , 4" Long (Used as spacers to allow hand grips to fit)	Ace Hardware	Qty. 2	\$.91 per ft.
#62	97045K54	Hand Grip, Vinyl, Black, 7/8" (For Hand Pedals, Same As Part Used For Tiller Handle)	McMaster-Carr	Qty. 2	\$8.00/6 approx.

<u>HARDWARE</u>

□ #63		7/8" O.D. x" Wall Aluminium Tube (For Rear Axle Spacers)	ACE Hardware	Qty	\$
□ #64	90279A197	8-32 x 3/4" Screws (For Chainwheel Cover)	McMaster-Carr	Qty. 5	\$3.82 per 100
□ #65	90480A009	8-32 Nuts (For Chainwheel Cover)	McMaster-Carr	Qty. 10	\$1.07 per 100
□ #66	90631A009	8-32 Nylon Insert Lock Nuts (For Chainwheel Cover)	McMaster-Carr	Qty. 5	\$1.95 per 100
□ #67	92005A320	5mm Screws, 10mm long (For Seat Surfaces)	McMaster-Carr	Qty. 8	\$4.08 per 100
□ #68	98965A210	5mm Tee Nuts, 8mm Long, 6.5mm Barrel OD (For Seat Surfaces)	McMaster-Carr	Qty. 8	\$13.12 per 100

□ #69	92865A591	5/16"-18 TPI x 2" Bolt (For Steering Tube Clamp)	McMaster-Carr	Qty. 1	\$10.37 per 100
□ #70	92865A583	5/16"-18 TPI x 1" Bolts (For General Assembly)	McMaster-Carr	Qty. 6	\$8.16 per 100
□ #71	95462A030	5/16"-18 TPI x 1" Nuts (For General Assembly)	McMaster-Carr	Qty. 7	\$2.92 per 100
□ #72	91102A755	5/16" Lock Washers (For General Assembly)	McMaster-Carr	Qty. 7	\$1.95 per 100
□ #73	90271A546	1/4"-20 TPI x 1.5" Screws (For Foot Rest)	McMaster-Carr	Qty. 4	\$10.18 per 100
□ #74	95615A120	1/4"-20 TPI Lock Nuts (For Foot Rest)	McMaster-Carr	Qty. 4	\$3.64 per 100
□ #75	90108A035	5/8" flat washers (For Axles If Needed)	McMaster-Carr	Qty. 6	\$12.60 per 65
□ #76	98338A478	Cotter pins, 1/8 x 1-1/2" (For Axles)	McMaster-Carr	Qty. 3	\$21.20 per 1K
□ #77	N/A	7/8" x .065 Wall Steel Tube (For Brake Tiller)		Qty. 1	\$